

SATTLER

LIGHT IN NEW DIMENSIONS

CLEANING INSTRUCTIONS

CLEANING SET

1 x white cotton gloves
2 x microfiber cloths

The fixture consists out of an aluminium profile and an opal diffuser.

Do not use commercially available detergents.

The white cotton gloves are compulsory for cleaning staff during cleaning.

Light fittings with current carrying steel cables need to be **switched off** before cleaning.

It is generally recommended to disconnect the luminaire from the power supply and let it cool down before cleaning.



CLEANING THE ALUMINUM PROFILE – POWDER COATED FINISHES

Take one of the microfiber cloths and get some clean water on it so that it is damp.

With little pressure go through the aluminum surface to remove any dust or stains found on it. They should come off quite easily as the coating makes it difficult for tough stains to form.



CLEANING THE ALUMINUM PROFILE – POLISHED FINISHES

You have chosen a luminaire with an exquisite **hand-polished surface**. This sophisticated way of processing requires genuine craftsmanship, which may leave faint brush marks. This does not constitute a flaw in quality, but is instead a feature of handcrafted art.

Clean these surfaces exclusively with a soft, clean and dry cotton cloth.



CLEANING THE DIFFUSER

Take another of the microfiber cloths and get some clean water on it so that it is damp. Never use a dry cloth.

For this part we recommend antistatic cleaning agents for plastics, which have many advantages, please read very clearly the directions for use of the agent you will be using.

Moisten a cleaning cloth with the antistatic cleaning agents for plastics and wipe crosswise. Don't wipe to dry, but let it dry by itself.

Remember: do **not** use cleaning agents with abrasive substances to clean the diffuser.

CLEANING ACOUSTIC FABRIC

The acoustic cloth can be wiped with a dry or damp cloth or vacuumed when it is lightly stained.

Should this treatment not prove sufficient, the fabric can be removed from the luminaire and washed at 30°C.

Only authorized technicians may remove the fabric and put it back on in order to prevent any damage to the luminaire.

Washing Instructions: 

SATTLER

LIGHT IN NEW DIMENSIONS

FOR FURTHER REQUESTS PLEASE CONTACT:

T. +49 (0) 7161 / 920 193 – 0

M. info@sattler-lighting.com

www.sattler-lighting.com